

 PT. MNA SERANG	WORKING INSTRUCTION CIRCUIT BREAKER REACTIVE MAINTENANCE	WI/MNASRG-E&I-19-002	
		Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	
		Page	1 of 1

Kegiatan maintenance / <i>Maintenance Activity</i>			
 		 	
Matikan sumber energi terkait dan lakukan pemasangan LOTO pada breaker dan key switch (<i>Shut down the energy & LOTO the preaker & key Switch</i>)		Bersihkan debu-debu dan material asing yang menempel pada Breaker. (<i>Clean the dust and dirt materials on the breaker</i>)	
			
Lepaskan baut yang menempel pada Terminal & CB . (<i>Remove the screw which connected to the terminal & Unplug the CB</i>)		Pasang CB yang baru & kencangkan baut . (<i>Connect the new CB & tighten the screw</i>)	