

|                                                                                                            |                                                  |  |                      |             |
|------------------------------------------------------------------------------------------------------------|--------------------------------------------------|--|----------------------|-------------|
| <br><b>PT. MNA SERANG</b> | <b>WORKING INSTRUCTION</b>                       |  | WI/MNASRG-E&I-19-112 |             |
|                                                                                                            | <b>INSTRUMENT<br/>PEREVNTIVE<br/>MAINTENANCE</b> |  | Dept.                | ENGINEERING |
|                                                                                                            |                                                  |  | Section              | E&I         |
|                                                                                                            |                                                  |  | Revision             | 0           |
|                                                                                                            |                                                  |  | Effective Date       |             |
|                                                                                                            |                                                  |  | Page                 | 1 of 1 page |

**Prosedur / Procedure**



Periksa apakah instrument terproteksi terhadap lingkungannya. *(Check if the Instrument protected/guarded appropriately against the environment)*

Check apakah ada kebocoran pada Instrument & jalur udara bertekanan *(Check if there's leakage to the instrument & compressed air line)*



Periksa apakah ada cable gland yang rusak, hilang, & longgar *(Check if there's any cable gland broken, missing, or loosened)*

Periksa apakah instrument, junction box, & Tray kabel dalam kondisi baik, dan cover instrument terpasang dengan baik *(Check if the instrument, JB & cable tray in a good condition & Instrument Cover installed properly)*



Periksa apakah instrument dalam kondisi bersih, tidak cacat, dan korosi < 10% permukaannya  
*Check if the instrument is clean, not defected, nor corroded for more than 10% of its body surface*

|  |  |
|--|--|
|  |  |
|--|--|

Lepaskan pressure dari comparison pump, dan bersihkan. *(Unninstal the pressure gauge from the comparison pump and cleaning)*

6. Lakukan analisa hasil pembacaan pressure gauge (Budget ketidakpastian)  
*Perform pressure gauge reading analysis (Budget uncertainty)*